



UŽIVATELSKÝ MANUÁL – CZ

IN 6496 Odrážedlo WORKER Gaudio (S1886S)



NÁVOD NA SESTAVENÍ

Vybalte obsah balení a zkontrolujte, zda jsou dodány všechny potřebné díly. Balení by mělo obsahovat hlavní rám se zadním kolem, řídítka, sedlo, přední vidlici s předním kolem a malý plastový sáček s objímkou řídítek, 2 krytkami a nářadím.

1. Vsuňte přední vidlici do hlavního rámu.
 2. Nasad'te objímku shora na přední vidlici.
 3. Zdola nasuňte na řídítka krytku objímky. Poté vsuňte řídítka do přední vidlice.
 4. Pomocí klíče utáhněte objímku řídítek a nasad'te na ni krytku.
 5. Nasuňte na sedlovku zbývající krytku a poté vsuňte sedlovku do hlavního rámu. K fixaci sedlovky v rámu opět slouží upínací objímka. Šroub pro upevnění sedlové objímky utáhněte klíčem a nakonec zakryjte objímku krytkou.
- Pozici sedla a řídítek nastavte podle výšky dítěte. Před použitím pevně utáhněte všechny šrouby a matice.



2



3



4



5

DŮLEŽITÉ INFORMACE

1. Seřízení velikosti odrážedla:

Sedlo by mělo být v takové výšce, aby se dítě mohlo postavit na zem celou plochou chodidel s mírně pokrčenýma nohama v kolenou. Řídítka by měla být v takové pozici, aby byly při uchopení řídítek horní končetiny přibližně v horizontální poloze. Zkontrolujte, zda tato pozice dítěti vyhovuje. Pravidelně odrážedlo seřizujte podle aktuální výšky dítěte.

2. Začátky:

Pokud je dítě schopno zvednout odrážedlo ze země, dokáže na něm také jezdit. Není potřeba dítěti zdlouhavě vysvětlovat, jak odrážedlo používat, prostě to nechejte na něm a pouze dohlížejte na to, co s odrážedlem provádí. Děti se velmi dobře učí a tuto schopnost jen podpoříte, pokud je necháte, aby se naučily zacházet s odrážedlem samy. Obvykle najdou velice rychle způsob, jak se na odrážedle pohybovat a jak jej řídit. Dohlížejte na to, aby dítě sedělo na sedle a nikoliv na tyči rámu.

3. Odrážení:

Dítě by se mělo odrážet od země směrem dopředu střídavě levou a pravou nohou. Dítě dosáhne větší rychlosti a jízda bude pro něj snadnější, pokud se bude odrážet od špiček a dopadat na paty chodidel.

4. Vyrovnávání rovnováhy:

Při jízdě dítě vyrovnává rovnováhu především pomocí zad a hýždí. Jakmile si dítě osvojí tuto dovednost, dokáže ovládat i další jízdní prostředky pro děti. Jízda na odrážedle slouží k nácvičení rovnováhy, podporuje fyzický a duševní rozvoj, posiluje zádové svalstvo, zlepšuje celkovou koordinaci a pohybové schopnosti dítěte.

5. V případě, že dítě potřebuje pomoc:

Nechejte dítě, aby se posadilo na odrážedlo a chytilo se řídítek. Uchopte horní tyč rámu a pohybujte odrážedlem směrem doleva a doprava. Dítě si tak zvykne na tento nový druh pohybu a naučí se vyrovnávat rovnováhu.

6. Údržba:

Odrážedlo má robustní konstrukci a je vyrobeno z vysoce kvalitních materiálů, tudíž má velmi dlouhou životnost. Pravidelně odrážedlo čistěte pomocí suchého hadříku. K čištění velkých nečistot použijte čisticí prostředky na dřevo.

Maximální hmotnost dítěte nesmí přesahovat 35kg.

7. Venkovní a vnitřní použití:

Dítě může odrážedlo používat doma i venku. Dítě se nesmí pohybovat na silnicích nebo v jejich blízkosti bez dozoru dospělé osoby.

Varování! Při jízdě by mělo dítě používat ochrannou helmu! Montáž odrážedla musí provádět dospělá osoba!

ZÁRUČNÍ PODMÍNKY, REKLAMACE

Všeobecná ustanovení a vymezení pojmů

Tyto záruční podmínky a reklamační řád upravují podmínky a rozsah záruky poskytované prodávajícím na zboží dodávané kupujícím, jakož i postup při vyřizování reklamačních nároků uplatněných kupujícím na dodané zboží. Záruční podmínky a reklamační řád se řídí příslušnými ustanoveními zákona č. 40/1964 Sb., Občanský zákoník, zákona č. 513/1991 Sb., Obchodní zákoník, a zákona č. 634/1992 Sb., Zákon o ochraně spotřebitele, ve znění pozdějších předpisů, a to i ve věcech těmito záručními podmínkami a reklamačním řádem nezmiňovaných.

Prodávajícím je společnost SEVEN SPORT s.r.o. se sídlem Bořivojova 35/878, 13000 Praha, I.Č. 26847264, zapsaná v obchodním rejstříku, vedeném Krajským soudem v Praze oddíl C, vložka 116888.

Vzhledem k platné právní úpravě se rozlišuje kupující, který je spotřebitelem a kupující, který spotřebitelem není.

„Kupující spotřebitel“ nebo jen „spotřebitel“ je osoba, která při uzavírání a plnění smlouvy nejedná v rámci své obchodní nebo jiné podnikatelské činnosti.

„Kupující, který není „spotřebitel“, je podnikatel, který nakupuje výrobky či užívá služby za účelem svého podnikání s těmito výrobky nebo službami. Tento kupující se řídí rámcovou kupní smlouvou a obchodními podmínkami v rozsahu, které se ho týkají a obchodním zákoníkem.

Tyto záruční podmínky a reklamační řád jsou nedílnou součástí každé kupní smlouvy uzavřené mezi prodávajícím a kupujícím. Záruční podmínky a reklamační řád jsou platné a závazné, pokud v kupní smlouvě či v dodatku v této smlouvě či jiné písemné dohodě nebude stranami dohodnuto jinak.

Záruční podmínky

Záruční doba

Prodávající poskytuje kupujícím záruku za jakost zboží v délce 24 měsíců, pokud ze záručního listu, faktury ke zboží, dodacího listu, příp. jiného dokladu ke zboží nevyplývá odlišná délka záruční doby poskytovaná prodávajícím. Zákonná délka záruky poskytovaná spotřebiteli není tímto dotčena.

Zárukou za jakost přejímá prodávající závazek, že dodané zboží bude po určitou dobu způsobilé pro použití k obvyklému, příp. smluvenému účelu a že si zachová obvyklé, příp. smluvené vlastnosti.

Záruční podmínky se nevztahují na závady vzniklé:

zaviněním uživatele tj. poškození výrobku neodbornou repasí, nesprávnou montáží, nedostatečným zasunutím sedlové tyče do rámu, nedostatečným utáhnutím pedálů v klikách a klik ke středové ose

nesprávnou údržbou

mechanickým poškozením

opotřebením dílů při běžném používání (např. gumové a plastové části, pohyblivé mechanismy, atd.)

neodvratnou událostí, živelnou pohromou

neodbornými zásahy

nesprávným zacházením, či nevhodným umístěním, vlivem nízké nebo vysoké teploty, působením vody, neúměrným tlakem a nárazy, úmyslně pozměněným designem, tvarem nebo rozměry

Reklamační řád

Postup při reklamaci vady zboží

Kupující je povinen zboží, dodané prodávajícím prohlédnout co nejdříve po přechodu nebezpečí škody na zboží, resp. po jeho dodání. Prohlídku musí kupující provést tak, aby zjistil všechny vady, které je možné při přiměřené odborné prohlídce zjistit.

Při reklamaci zboží je kupující povinen na žádost prodávajícího prokázat nákup a oprávněnost reklamace fakturou nebo dodacím listem s uvedeným výrobním (sériovým) číslem, případně týmiž doklady bez sériového čísla. Neprokáže-li kupující oprávněnost reklamace těmito doklady, má prodávající právo reklamaci odmítnout.

Pokud kupující oznámí závadu, na kterou se nevztahuje záruka (např. nebyly splněny podmínky záruky, závada byla nahlášena omylem apod.), je prodávající oprávněn požadovat plnou úhradu nákladů, které vznikly

v souvislosti s odstraňováním závady takto oznámené kupujícím. Kalkulace servisního zásahu bude v tomto případě vycházet z platného ceníku pracovních výkonů a nákladů na dopravu.

Pokud prodávající zjistí (testováním), že reklamovaný výrobek není vadný, považuje se reklamační za neoprávněnou. Proávající si vyhrazuje právo požadovat úhradu nákladu, které vznikly v souvislosti s neoprávněnou reklamací.

V případě, že kupující reklamuje vady zboží, na které se vztahuje záruka podle platných záručních podmínek prodávajícího, provede prodávající odstranění vady formou opravy, případně výměny vadného dílu nebo zařízení za bezvadné. Proávající je se souhlasem kupujícího oprávněn dodat výměnou za vadné zboží jiné zboží plně funkčně kompatibilní, ale minimálně stejných nebo lepších technických parametrů. Volba ohledně způsobu vyřízení reklamační dle tohoto odstavce náleží prodávajícímu.

Proávající vyřídí reklamaci nejpozději do 30 dnů od doručení vadného zboží, pokud nebude dohodnuta lhůta delší. Za den vyřízení se považuje den, kdy bylo opravené nebo vyměněné zboží předáno kupujícímu. Není-li prodávající s ohledem na charakter vady schopen vyřídit reklamaci v uvedené lhůtě, dohodne s kupujícími náhradní řešení. Pokud k takové dohodě nedojde, je prodávající povinen poskytnout kupujícímu finanční náhradu formou dobropisu.



SEVEN SPORT, s. r. o.

Bořivojova 35/878 130 00 Praha 3, ČR IČO: 268 47 264, DIČ: CZ26847264
Objednávky: +420 556 300 970, objednavky@insportline.cz
Reklamační: +420 556 770 190, mobil: +420 604 853 019, reklamace@insportline.cz
Servis: +420 556 770 190, mobil: +420 604 853 019, servis@insportline.cz
Fax: +420 556 770 192, (servis +420 556 770 191)
Web: www.insportline.cz, www.worker.cz, www.worker-moto.cz



Zastoupení pro Slovensko:

INSPORTLINÉ, s.r.o., Bratislavská 36, 911 05 Trenčín, IČO: 36311723, DIČ: SK2020177082
Objednávky: +421(0)326 526 701, +421(0)917 649 192, objednavky@insportline.sk
Reklamační: +421(0)326 526 701, +421(0)918 408 519, reklamacie@insportline.sk
Fax: +421(0)326 526 705
Web: www.insportline.sk, www.worker.sk, www.worker-moto.sk

Datum prodeje:

Razítko a podpis prodeje:



USER MANUAL – EN

IN 6496 WORKER Gaudio Children Walking Bike (S1886S)



ASSEMBLY

Open the carton and check if all the parts are complete. It should be one main frame with rear wheel, one handlebar, one saddle, one fork with front wheel, and a small poly bag with one lock catch, 2 lock catch covers and tools.

1. Insert the fork stem into the steering tube of the main frame.
2. Put the lock into the end of the fork stem
3. Insert one of the lock catch cover into the handlebar stem. Then, insert the handlebar stem into the fork stem.
4. Use the spanner to tighten the lock catch and get the lock catch cover down.
5. Insert the other lock catch cover into the saddle post and then insert the saddle post into the saddle tube of the main frame where there is a welded lock catch. Tighten the lock catch with the spanner and get the lock catch cover down.

Adjust the height of the saddle and handlebar according to your kid height, and tighten all the screws and nuts before his/her riding.



IMPORTANT INFORMATION

1. Adjusting the walking bike:

Adjust the height of the saddle so that your child can easily touch the ground with the complete soles of his or her feet with slightly angled knees. The handlebar should be at a height that allows the arms to be held roughly horizontally. Test whether your child feels comfortable in this position and check the adjustments regularly.

2. First tries:

As soon as your child is able to pick up the walking bike from the ground, it is capable of riding it, too. There is no need for long explanations, just let the child try and watch what he or she does with it. Children are masters in learning, and you strengthen this possibility by letting them do. Normally, they find out rather quickly how the device can be moved and steered. Mind that your child is really sitting on the saddle and not on the link.

3. Rolling:

Push forward off the ground with left and right foot in alternation. The more smoothly the feet roll off from toes to heel, the easier and faster your child will go.

4. Steering:

The easiest way to steer the walking bike is with back and bum. As soon as your child has understood this knack, he or she will drive around with it as jauntily as with any other vehicle, too. With the subtle distinction that this walking bike trains sense of balance, stimulates the physical and mental development, strengthens the back and makes your child like movements all in all more secure and sportive.

5. In case your child needs a helping hand:

Let your child sit on the walking bike with the hands on the handlebar ends and move the bike's link from left to right. The child will feel the new kind of movement and reproduce it independently soon afterwards.

6. Handling and maintenance:

The walking bike is of robust built and made of high-quality products and therefore can stand quite a lot of wear and tear. Wipe the bike down with a dry cloth regularly and use a nurturing wood agent if it has been soiled.

The allowed maximum weight for the use of the walking bike is 35 kg.

7. Indoor and outdoor use:

The kiddy can be ridden indoors as well as outdoors. Please take care that your child is not riding along or on any streets unsupervised.

Warning! A protective helmet should be worn when cycling! The toy shall be assembled by adult!

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from:

User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks

Improper maintenance

Mechanical damages

Regular use (e.g. wearing out of rubber and plastic parts, joints etc.)

Unavoidable event, natural disaster

Adjustments made by unqualified person

Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to

require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT, s.r.o.

Borivojova 35/878 130 00 Praha 3, Czech Republic

CRN: 268 47 264, VAT ID: CZ26847264

Orders: +420 556 300 970, objednavky@insportline.cz

Warranty Claims: +420 556 770 190, Mobile: +420 604 853 019, reklamace@insportline.cz

Service: +420 556 770 190, Mobile: +420 604 853 019, servis@insportline.cz

Fax: +420 556 770 192, (Service +420 556 770 191)

Web: www.insportline.cz, www.worker.cz, www.worker-moto.cz



INSPORTLINE, s.r.o.

Bratislavská 36, 911 05 Trenčín, Slovakia

CRN: 36311723, VAT ID: SK2020177082

Orders: +421(0)326 526 701, +421(0)917 649 192, objednavky@insportline.sk

Warranty Claims: +421(0)326 526 701, +421(0)918 408 519, reklamacie@insportline.sk

Fax: +421(0)326 526 705

Web: www.insportline.sk, www.worker.sk, www.worker-moto.sk

Date of Sale:

Stamp and Signature of Seller: