




USER MANUAL – EN

IN 23261 Spin Bike inSPORTline inCondi S200i




CONTENTS


- SAFETY INSTRUCTIONS..... 3
- DIAGRAM..... 4
- PARTS LIST 6
- ASSEMBLY 9
- CONSOLE 15
 - PROGRAMS 17
- IMPORTANT NOTES 21
- USE 22
- CORRECT BODY POSTURE 22
- EXERCISE INSTRUCTIONS 22
- MAINTENANCE 24
- STORAGE 24
- IMPORTANT NOTICE 24
- ENVIRONMENT PROTECTION 24
- TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 24

SAFETY INSTRUCTIONS

- Read the manual carefully before use and assembly and keep it for future reference.
- To ensure the best safety of the exerciser, regularly check it on damages and worn parts.
- If you pass on this exerciser to another person or if you allow another person to use it, make sure that that person is familiar with the content and instructions in these instructions.
- Only one person should use the exerciser at a time.
- Before the first use and regularly make sure that all screws, bolts and other joints are properly tightened and firmly seated.
- Before you start your work-out, remove all sharp-edged objects around the exerciser.
- Only use the exercise for your work-out if it works flawlessly.
- Any broken, worn or defective part must immediately be replaced and/or the exerciser must no longer be used until it has been properly maintained and repaired.
- Parents and other supervisory persons should be aware of their responsibility, due to situations which may arise for which the exerciser has not been designed and which may occur due to children's natural play instinct and interest in experimenting.
- If you do allow children to use this exerciser, be sure to take into consideration and assess their mental and physical condition and development, and above all their temperament. Children should use the exerciser only under adult supervision and be instructed on the correct and proper use of the exerciser. The exerciser is not a toy.
- Make sure there is sufficient free space around the exerciser when you set it up at least 0.6 m.
- To avoid possible accidents, do not allow children to approach the exerciser without supervision, since they may use it in a way for which it is not intended due to their natural play instinct and interest in experimenting.
- Please note that an improper and excessive work-out may be harmful to your health.
- Please note that levers and other adjustment mechanisms are not projecting into the area of movement during the work-out.
- When setting up the exerciser, please make sure that the exerciser is standing in a stable way and that any possible unevenness of the floor is evened out.
- Always wear appropriate clothing and shoes which are suitable for your work-out on the exerciser. The clothes must be designed in a way so that they will not get caught in any part of the exerciser during the work-out due to their form (for example, length). Be sure to wear appropriate shoes which are suitable for the work-out, firmly support the feet and which are provided with a non-slip sole.
- Be sure to consult a physician before you start any exercise program. He may give you proper hints and advice with respect to the individual intensity of stress for you as well as to your work-out and sensible eating habits.
- If you do not use the spinning bike, increase the resistance to the maximum to prevent the flywheel from moving.
- **Maximal weight limit:** 130 kg
- **Category:** HC for home use according to EN 957

DIAGRAM





PARTS LIST





No.	Name	Qty.	Specifications
1.	Console	1	
2.	Top cover of the right handle	1	
3.	Hexagon socket head cap screw	4	M5*35
4.	Square cover	1	
5.	Bottom cover of the right handle	1	
6.	Top cover of the left handle	1	
7.	Console holder	1	
8.	Bottom cover of the left handle	1	
9.	Bolt	6	ST3*16*Φ5.6
10.	Handles	1	
11.	Washer	3	
12.	Spring washer	2	
13.	Hand knob	1	
14.	Bolt	2	
15.	Pedals	1pair	
16.	Cranks	1pair	
17.	Nut caps	4	
18.	Washer	4	
19.	Curved washer	4	d8*Φ20*2*R38
20.	Bolt	2	Φ7.8*30*M6*15*S5
21.	Transport wheels	2	
22.	Washer	2	d6*Φ12*1.5
23.	Bolt	2	M6*12*S5
24.	Round cap	4	Φ76
25.	Front stabilizer	1	
26.	Nut	4	M8*H5.5*S14
27.	Hand knob	4	
28.	Main frame	1	
29.	Hexagon socket head cap screw	4	M8*90*20*H5
30.	Rear stabilizer	1	
31.	Hand knob with spring	1	
32.	Seat post	1	
33.	End cap	2	D28
34.	Seat	1	
35.	Handle holder	1	


36.	Square end cap	1	
37.	Tablet holder	1	
38.	Round cap	2	
39.	Nut	2	M10*1.25*H7.5*S14
40.	Decorative cover	2	
41.	Plastic cover	2	
42.	Bolt	7	ST4.2*19*Φ8
43.	Right belt cover	1	
44.	Connecting frame	5	
45.	Nylon nut	4	
46.	Flexible washer	4	
47.	Shaft	1	
48.	Shaft spacer ring	1	
49.	Washer	1	d20*Φ26*0.3
50.	Pulleys	1	
51.	Round magnet	1	
52.	Bolt	4	M6*16*S10
53.	Belt	1	
54.	Bearings	2	
55.	Upper right seat post cover	1	
56.	Nylon nut	1	M10*H9.5*S17
57.	Freewheel shaft	1	
58.	Washer	1	d12*Φ15.5*0.3
59.	Bearings	2	
60.	Flywheel	1	
61.	Nut	2	M10*1*H8*S15
62.	Adjustable chain	2	
63.	Nut	1	M10*1*H5*S17
64.	Washer	1	d6*Φ16*1.5
65.	Bolt	1	M6*10*S10
66.	Motor	1	
67.	Sensor	1	
68.	Bolt	9	ST4.2*16*Φ8
69.	Bottom left seat post cover	1	
70.	Flywheel	1	
71.	Ring	1	d20
72.	Nut	1	M10*1*H5*S17
73.	Top left seat post cover	1	

74.	Bolt	4	ST4.2*6*φ8
75.	Left belt cover		
76.	Bolt		ST4.2*25*Φ8
77.	Left handle holder cover		
78.	Bottom cover		
79.	Hexagon socket head cap screw		M5*10*φ10
80.	Lower right seat post cover		
81.	Stopping shaft		
82.	Bushing		
83.	Top cover	1	
84.	Housing	2	
85.	Right handle holder cover	1	
86.	Hexagon socket head cap screw	1	M5*18*φ8
87.	Stopper block	2	
88.	Rubber band	1	
89.	Lower saddle travel	1	
90.	Saddle travel	1	
91.	Square ending	2	
92.	Rubber pad	1	
93.	Saddle stopper	1	
94.	Bolt	2	M4*12*φ7
95.	Pin	1	
96.	Square spacer	1	
97.	Lever	1	
98.	Washer	1	d5*φ14*2
99.	Hexagon socket head cap screw	1	M5*16*Φ10
100.	Crank cover	2	
101.	Packaging beams	2	
102.	Adapter	1	
103.	Resistance cable	1	
104.	Cable 1	1	
105.	Cable 2	1	
106.	Pulse cable	1	
107.	Bolt	2	
A	Allen key	1	S8
B	Key	1	S13-14-15
C	Allen key	1	S5

ASSEMBLY


PARTS LIST

		
1. console 1x	7. console holder 1x	10. handles 1x
		
15. pedals 1x pair	25. front stabilizer	30. rear stabilizer
		
34. seat 1x	37. tablet holder	hardware 1x
		
102. adapter 1x	28. main frame 1x	




STEP 1

You must remove the preinstalled stabilizers before attaching the stabilizers. Fasten the front and rear stabilizers (25 and 30) with 4x bolts (29), 4x curved washers (19), 4x washers (18) and 4x nuts (17).




STEP 2

Before attaching the handles, connect the cables. Make sure that the cables (a, b) do not pinch, damage or fall into the frame. First attach the console holder (7) with 2x bolts (107) and then the handle (10) with 2x bolts (14), 2x washers (12) and 2x washers (11). Pay attention to the direction of the handles (10).




STEP 3

Connect the cables before attaching the console (1). Be careful not to pinch the cables. Attach the console (1) to the console holder (7) together with the tablet holder (37) with 2x bolts (3).




STEP 4

Attach the seat (34) to the seat post (32) with nut. Tighten the nut with a wrench.




STEP 5

The pedals are marked L (left) and R (right). Tighten the pedals with a wrench.



STEP 6

Plug in the adapter and plug it into an electrical outlet.



Prior to use, make sure that all parts are properly attached and tightened.

TRANSPORT


WARNING: Depending on your physical abilities, ask another person for help. Be careful.

Unplug the power cord.

Carefully place the spin bike on the transport wheels.

Carefully push the spin bike.

Carefully place the spin bike.



WARNING


You must level the device before use.

Place the device where you will use it.


Sit on the exercise bike and let the device settle in place.

Loosen the nuts and adjust the height of the leveling feet as needed. Then tighten the nuts again.


WARNING: Be careful not to unscrew the leveling feet. The device must be stable before use!



COVER REMOVAL



CONSOLE




Display and buttons	Description	Range
TIME	Current exercise time	0m:00s – 99m:00s
SPEED	Current speed	0,0 – 99,9 km/h (mile/h)
DISTANCE	Current distance	0,00 – 99,99 km (mile)
AVERAGE SPEED	Average speed	0,0 99,9 km/h (mile /h)
CALORIES	Approximate calories burned	0 – 999 cal
PULSE	Approximate pulse during exercise	40 – 240 BPM
RPM	Revolutions per minute	0 – 999 RPM
WATT	Performance	0 -899 W
GEAR	24 resistance levels	
FRONT	Front wheel resistance adjustment	1 – 3
REAR	Rear wheel resistance adjustment	1 – 8
FRONT + / -	Front wheel resistance change (left handle)	
REAR + / -	Rear wheel resistance change (right handle)	

PROGRAM DESCRIPTION


Name	Description
MANUAL	Manual program, custom resistance setting
PROGRAM	Preset programs: P1 (ride uphill) / P2 (ride in the mountains) / P3 (ride on the road) / P4 (interval program) / P5 (relaxation program) / P6 (race)
BODY FAT	Body fat test
HRC	A program that adjusts the resistance according to the current heart rate
USER PROGRAM	User programs U1 / U2 / U3 / U4 user programs
Bluetooth	Bluetooth connection
Wireless pulse	Support 5.3 KHz chest strap frequencies

BUTTONS

Model with buttons



Model with touch screen




Button	Description
	Navigation button up, increase value, increase resistance during exercise
	Navigation button down, decrease value, reduce resistance during exercise
	Return to manual mode in any program (except programs U1 - U4, FAT and HRC), data reset
	Heart rate recovery test
	If the program is stopped, change the program
	Starts / stops the program

UNITS

Height	Weight	Pulse	Calories	Distance	Speed	RPM	Watts
cm (inches)	kg (lbs)	BPM	Kcal	km / miles	km/h (miles/h)	RPM	W

PROGRAMS

MANUAL



Press to start program.

Press to set up values, the set value will flash.


Use to adjust values, press to confirm.

During exercise the resistance is changed according to the program or with buttons.

If the time, distance, or calorie value is set as a countdown, after reaching 0 the program will automatically shut down and an audible signal will sound.

You can stop the program by pressing button.

PRESET PROGRAMS



Press and select program: P1 (ride uphill) / P2 (ride in the mountains) / P3 (ride on the road) / P4 (interval program) / P5 (relaxation program) / P6 (race)

Press to start program or press to enter settings.

Press to adjust value, confirm by pressing button, next value is displayed.


After setting up all values you will leave the settings or press button to leave the settings.

During exercise, the resistance is adjusted according to the program, or you can adjust the resistance using the buttons.

If the time, distance, or calorie value is set as a countdown, after reaching 0 the program will automatically shut down and an audible signal will sound.

You can stop the program by pressing  button.

BODY FAT



Press  to enter settings.

Set gender – height – weight – age. Press   to adjust values.

M (male), F (female)

After setting up the values press , test will start in 8 seconds. Then BMI and FAT% and BMR are displayed.

You must hold heart rate sensors before and during testing.

The test should be performed at normal heart rate and at rest.

BMI

Gender	Skinny	Normal	Mild overweight	Overweight	Obesity
Man ≤ 30	< 14	14 ~ 20	20.1 ~ 25	25.1 ~ 35	> 35
Man > 30	< 17	17 ~ 23	23.1 ~ 28	28.1 ~ 38	> 38
Female ≤ 30	< 17	17 ~ 24	24.1 ~ 30	30.1 ~ 40	> 40
Female > 30	< 20	20 ~ 27	27.1 ~ 33	33.1 ~ 43	> 43

FAT%


Gender	Low	Medium	Above average	High
Man	<	13% -25.9%	26% -30%	> 30%
Female	<	23% -35.9%	36% -40%	> 40%

BODY TYPE

B1	B2	B3	B4	B5	B6	B7	B8	B9
Extreme malnutrition	Malnutrition	Mild malnutrition	Below average	Average	Above average	Overweight	Obesity	Extreme obesity

WARNING: BMI, FAT%, and TYPE POINTS ARE FOR INDICATIVE PURPOSES ONLY AND CAN NOT BE USED FOR DIAGNOSTICS HEALTH ISSUES.

HRC



Press to enter settings. Order: time – distance – calories – target heart rate.

Press to adjust values.


Press to start program. Resistance is adjusted according to the set target heart rate

If the countdown is set, after reaching 0 the program will automatically shut down and an audible signal will sound.

You can stop the program by pressing button.

If the heart rate cannot be detected, the program will continue but the resistance will not change.

USER PROGRAM



Press to select program U1 – U4.

Press to start or press to enter settings.

In settings, you can adjust the values in this order: time - distance - calories - resistance, for each training segment.


Press to adjust values, press to confirm and move to the next training segment.

Press to start. During exercise press to adjust resistance.

If the countdown is set, after reaching 0 the program will automatically shut down and an audible signal will sound.

You can stop the program by pressing  button.

RECOVERY



Heart rate recovery test.

Během cvičení a měření tepové frekvence, stiskněte   a držte senzory tepové frekvence.

The 0:60 countdown is displayed.

When the time reaches 0, the result F1 - F6 is displayed.

It is recommended to measure after aerobic exercise.

F1 = 1.0	Optimal
1.0 < F1 <2.0	Good
2.0 < F1 <2.9	Above average
3.0 < F1 <3.9	Normal
4.0 < F1 <5.9	Below the average
F6 = 6.0	Bad

BLUETOOTH

Start Bluetooth on your smart device and launch the FitShow application and press "Search device".

Select the device and press "connect". The Bluetooth icon is displayed.

Select a scenery.


Press START.

Press CONTROL to allow the application to control your device and display the application information.

Press STOP to stop the program and stop recording information.

CHEST BELT

The device is compatible with a chest band with a frequency of 5.3 Khz. During exercise, an indicator is displayed that the chest strap is attached. In order for the belt to send the most accurate information possible, the chest belt must be firmly attached and the sensors must be on the skin.



Slightly moisten the sensors. Set the correct belt length. Make sure you have the belt fitted correctly.

CHYBOVÉ ZPRÁVY

No.	Possible Cause	Check	Possible Solution
E1	The engine does not work	Motor connection	Poor connection or engine damage
	Improperly connected / damaged cables	Cables	Replace the cables
	The display does not show the correct information		Replace the console
E2	You do not hold the sensors during the body fat test		Hold the sensors for at least 3 seconds before testing
	The console does not detect heart rate		Replace the display, sensors or cables

The console is powered by 9V / 1A. If the console does not work properly, disconnect and reconnect the adapter.

If the device is not operated for 5 minutes, the power save mode starts.

IMPORTANT NOTES

- Assemble the exerciser as per assembly instructions and be sure to only use the structural parts provided with the exerciser and designed for it. Prior to the assembly, make sure the contents of the delivery are complete by referring to the parts list of the assembly and operating instructions.
- Be sure to set up the exerciser in a dry and even place and always protect it from humidity. If you wish to protect the place particularly against pressure points, contamination, etc., it is recommended to put a suitable, non-slip mat under the exerciser.
- The general rule is that exercisers and training devices are no toys. Therefore, they must only be used by properly informed or instructed persons.
- Stop your work-out immediately in case of dizziness, nausea, chest pain or any other physical symptoms. In case of doubt, consult your physician immediately.
- Children, disabled and handicapped persons should use the exercise only under supervision and in presence of another person who may give support and useful instructions.
- Be sure that your body parts and those of other persons are never close to any moving parts of the exerciser during its use.
- When adjusting the adjustable parts, make sure they are adjusted properly and note the marked, maximum adjusting position, for example of the saddle support, respectively.
- Do not work out immediately after meals!
- **WARNING! A system for monitoring heart rate may not be accurate. Overloading during training may cause serious injury or death. If you feel any discomfort, immediately stop the exercise!**

USE

Exercise on the spinning bike is based on very simple movements, but you will surely fall in love with them. Thanks to simplicity of the exercise on the spinning bike it can be done by elderly people. Prior to exercise, it is necessary to adjust the height of the saddle. It is important that you sit comfortably. The bicycle saddle must be set so that you can hold the ergonomically shaped handles when sitting. You should not have fully extended hands. You can damage your muscles.

To ensure a comfortable and comfortable exercise, put your feet on the pedal. Nowadays, all modern pedals are equipped with straps for fastening and stabilizing of the foot. It is important for your foot to be firmly and safely positioned during exercise.

The basis of exercising on a bicycle is that the legs are moving on a specific elliptical path. This movement is very similar to cycling. When doing exercise on a bicycle, you just sit on the saddle with the right height, keep your feet firmly in the pedals, hold the ergonomically shaped handles and exercise.

It is advisable at the beginning to choose a lower load. If you exercise at regular intervals on a spinning bike, you can gradually increase the load. You can increase the load gradually over a week or two weeks. Selecting a high load during the start of training can lead to rapid fatigue and muscle damage.

When exercising, it's important to choose the right load and the right tempo. Try to keep it throughout the exercise. It is not recommended to choose a high pace right from the start. Increase tempo after about a week of regular exercise. The high pace is not equal to the faster burning of calories. Correct calorie burning is reflected in an appropriate and regular exercise. At the beginning of the exercise, the number of burned calories may seem low, but regular and appropriate exercise is the key to achieving the best results.

Exercise on the spinning bike also leads to the formation of muscles. It is mainly used to strengthen the thigh and calf muscles. While exercising on a bicycle, you also move your buttocks.

If you want to exercise right, you should not forget to breathe properly. Proper and regular breathing is recommended in any exercise. It is important to keep regular deep inhales and exhales. Regular and proper breathing during exercises on the spinning bike involves intense exercise of the abdominal muscles. It is advisable to practice 30-35 after consuming food. Failure to do so may result in less calories burned, and in older age even lead to digestive problems.

For best results, you should also consider your diet. It is recommended to start a day of eating sweet food and pastries or muesli with milk. For lunch is recommended to eat a caloric richer meal. Do not forget about the soup. In the evening, light meals are recommended. If you want to improve your health, it's not just a regular exercise but a whole diet.

Bicycle exercise is an effective exercise for all busy people. Exercise on the spinning bike is effective in strengthening muscles, especially thighs, calves and buttocks. Regular exercise can lead to a slimmer figure. Exercise is recommended not only as a winter training for cyclists but also for people who want to burn excess calories. Regular breathing, regular exercise, reasonable tempo, and balanced diet can lead to your desired results.

CORRECT BODY POSTURE

When training, keep your body upright, or you can learn your hand on your forearms. During pedaling, you should not have your legs fully extended. Your knees should be slightly bent when fully pressing down the pedal. Keep your head straight with your spine to minimize the pain of the cervical muscles and upper back muscles. Always exercise fluently and rhythmically.

EXERCISE INSTRUCTIONS

A successful workout begins with warm-up exercises and ends with cool-down (relaxing) exercises. The warm-up exercises should make your body ready for the main workout. The cool-down phase should protect your muscles from injuries and cramps. Do warm-up and cool-down exercises as shown in the chart below.



Touching your toes

Slowly bend your back from hips. Keep your back and arms relaxed while stretching downwards to your toes. Do it as far as you are able and hold the position for 15 seconds. Bend your knees slightly



Upper thigh

Lean against a wall with one hand. Reach down and behind you. Lift up your right or left foot to your buttock as high as possible. Keep for 30 seconds and repeat twice for each leg.



Hamstring stretched

Sit and outstretch your right leg. Rest the sole of your left foot against the inside of your right thigh. Stretch out your right arm along your right leg as far as you can. Hold for 15 seconds and relax. Repeat all with your left leg and left arm



Inside upper thigh


Sit on the floor and place your feet together. Knees are pointed outwards. Pull your feet as close as possible to your groin. Press your knees carefully downwards. Keep this position for 30-40 seconds if possible.



Calves and Achilles tendon

Lean against a wall with your left leg in front of the right one and your arms forward. Stretch out your right leg and keep your left foot on the floor. Bend your left leg and lean forwards by moving your right hip in the direction of the wall. Hold for 15 seconds. Keep your leg stretched and repeat exercising with other leg.

Exercise Stage. Regular exercise will make your muscles stronger. Keep the pace according to the chart during the training. Training should take at least 12 minutes.



Then let the muscles calm down by reducing the pace for approx. 5 min. Then do the warm-up exercises. Train regularly at least 3 times a week.

MAINTENANCE

- When assembling, tighten all screws and adjust the bike to the horizontal position.
- Check the screws after 10 hours of use.
- Wipe the sweat after the exercise. Clean the device with a cloth and gentle cleanser. Do not use solvents or aggressive cleaners on the plastic parts.
- When noise is increased, it is necessary to check that all joints are tightened properly.
- Place the product in a clean, ventilated and dry room.
- Do not expose the device to direct sunlight.

STORAGE

Keep the spinning bike in a clean and dry environment. Make sure the power switch is turned off and the spinning bike is not plugged into the power socket.

IMPORTANT NOTICE

- This spinning bike comes with standard safety regulations. Any other use is prohibited and may be dangerous to users. We are not responsible for any injury caused by improper and forbidden use of the machine.
- Consult your doctor before starting training on the spinning bike. Your doctor should evaluate whether you are physically fit to use the machine and how much effort you are able to undergo. Incorrect exercise or switching of the body can harm your health.
- Carefully read the following tips and exercises. If you experience pain, nausea, breathing, or other health problems during exercise, immediately stop the exercise. If the pain persists, contact your doctor immediately.
- This spinning bike is not suitable for medical purpose. It can also not be used for healing purposes.
- The heart rate monitor is not a medical device. It provides only approximate information about your average heart rate, and any suggested pulse rate is not medically binding. Accumulated data may not always be accurate regarding uncontrollable human and environmental factors.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ
SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK
inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
VAT ID: SK2020177082

Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk