



AZTRON

RIDE INTELLIGENTLY

AZTRONSPORTS.COM

USER MANUAL – EN

Solid paddleboard Eclipse (softboard)

CONTENTS

SAFETY INSTRUCTIONS.....	3
GENERAL PADDLING INFORMATION.....	3
SAFETY	3
PRODUCT DESCRIPTION	4
GENERAL INFORMATION	5
FIN INSTALATION	7
PADDLE AND LEASH.....	8
TRANSPORTACE	9
CARE AND MAINTENANCE.....	9
STORAGE	10
ENVIRONMENT PROTECTION	10
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	10

SAFETY INSTRUCTIONS

WARNING! For your own safety and that your equipment, make sure to take the following precautions. Failure to follow warning notices and instruction may result in property damage, serious injury or death.

GENERAL PADDLING INFORMATION

This manual has been compiled to help you operate your inflatable Stand Up Paddleboard with safety and pleasure. It contains details of the supplied equipment, and information on their operation. Please read it carefully and familiarize yourself with the ISUP before using it.

SAFETY


Paddle sports can be dangerous and physically demanding. Users of this product should understand participating in stand-up paddling result in serious injury or death. Observe all applicable watercraft laws and use common sense.

Mandatory instructions

- Wear personal flotation device and personal protection equipment.
- Read instructions first.
- Fully inflate all air chambers.
- Numbers of users, one adult.
- Safe distance to shore 150 m
- Don't use in braking waves.
- Don't use in offshore current.
- Don't use in offshore wind.
- Not for children 14 years of age and below.
- Design working pressure.
- No protection against drowning.
- Swimmers only.
- Always supervise children in water.
- Do not use alcohol or other addictive substances.
- Check equipment before use.
- Always familiarize yourself with the waters before using paddleboard.
- It is advisable to have an escort.
- Never tow a paddleboard boat.
- We recommend using special anti-slip shoes.
- When using in rivers not use safety leash, the paddleboard can drag you in the river.
- Do not use in bad weather conditions.

PRODUCT DESCRIPTION

You can find 12-digit serial number on the handle.



GENERAL INFORMATION

Prepare before use. Make sure the paddle length is adjusted to your height. Take the paddleboard to the water behind the holder in the middle of the paddleboard.



Get on the board with your knees left and right of the handle and get a feel for the balance of the board in the water.



Once you feel more comfortable, take the paddle and make your first strokes on your knees to feel the reaction of the board.



To stand up, place your paddle sideways over the board for stability and push yourself up with the paddle in both hands. Place your feet left and right of the center handle with about a shoulder wide spread. Having the blade in the water will help with stability and stops the board from moving forward or backwards.



Take your first stroke with one hand on the shaft and the other hand on the handle. Note, the blade will be tilted forward, towards the nose of the board. Change sides ever 3-5 strokes to paddle in a straight direction.




To change direction, take long extended strokes just on one side to steer the nose of the board in a new direction. If you're more advanced, take a step towards the tail of the board to reduce the turning radius for a quicker direction change. Take your first stroke with one hand on the shaft and the other hand on the handle. Note, the blade will be tilted forward, towards the nose of the board. Change sides ever 3-5 strokes to paddle in a straight direction.



FIN INSTALATION

Attach the fin firmly before using your SUP. Remove the fin after each use to keep it in good condition. The fin box, watertight skin and foam core may be badly damaged if the fin is damaged when it is attached to the SUP.

Unscrew the bot and the square nut from the fin.



Insert the nut into the SUP's groove and push forward.



Insert the fin into the SUP's groove and align the bolt's hole with the nut previously installed. Screw lightly and push backwards.



Place the bolt and screw firmly.



PADDLE AND LEASH

For maximum comfort, make sure you have properly adjusted your paddle length for your height. To find your preferred length, lift your arm to the paddle shaft in a 90 °C angel and extend the handle into your hand as a good starting point to find your preference.



When holding your paddle, your hands should be just over a shoulder width part. One hand holds the handle, the other is holding the shaft with a loose grip.



The marks on the extension of the handle assist you to find and return to your preferred length easily.



The blade of the paddle has a slight angle, which should point forward, toward the nose of the board.



Safety leash is the most important tool of SUP paddling. Aztron makes the safety leash as a standard accessory for our Soft Top boards.



If you paddle on a large body of water (lake or ocean), ensure to use an ankle leash so you are connected to your board all the times. This will prevent your board from floating away from you if you fall.



TRANSPORTACE

Hand: Carry the board by using the carrying handle.

Car: When strapping to the top of your car, place the SUP underside up. Placing the top side up may generate wind drag and instability when driving.

Place the front or the back of the SUP forward are both acceptable.

Overtightening straps may result in pressure dings. Use padded strap instead of non-padded nylon straps.



CARE AND MAINTENANCE

- The best way to clean your soft top board is to rinse it with fresh water to remove sand and saltwater deposits. Do not use abrasives.
- Inspect your board for dings and cracks before and after each use. The EPS Core of your soft top board is highly absorbent and acts as a sponge when protective watertight epoxy skin is compromised.

- Minor abrasions, dents, wearing off and scratches are normal and will not impact your SUP's performance.

STORAGE

- Keep your soft top board in a well-ventilated and shaded area when you do not use it. Your board can be damaged if it is exposed to direct sunlight for a period of time.
- Limit the exposure of the deck-side of the board to direct sunlight. While in use, water flowing over the deck helps regulate surface temperature. However, when the deck traction pad is dry, the heat absorption effect is amplified when exposed to direct sunlight.
- At approximately 74°C/165°F, the EPS foam begins outgassing, becomes unstable and delaminates.
- Leaving your board in a vehicle during the day, even on a mild day, increases the risk of delamination.
- Do not store your board in a SUP bag for extended period of time. SUP bags are intended for transportation only, not for full time storage. Prolonged storage of a wet SUP in a wet bag may lead to the possibility of mold and osmotic blisters. SUP bag also collects and can potentially overheat your board.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**SEVEN SPORT s.r.o.**

Registered Office:

Headquarters:

Warranty & Service Centre:

CRN:

VAT ID:

Phone:

E-mail:

Borivojova 35/878, 130 00 Praha 3, Czech Republic

Delnicka 957, 749 01 Vitkov, Czech Republic

Cermenska 486, 749 01 Vitkov, Czech Republic

26847264

CZ26847264

+420 556 300 970

eshop@insportline.cz

reklamace@insportline.cz

servis@insportline.cz

Web:

www.insportline.cz

SK**INSPORTLINE s.r.o.**

Headquarters, Warranty & Service centre:

Elektricka 6471, 911 01 Trenčin, Slovakia

CRN: 36311723

VAT ID: SK2020177082

Phone:

E-mail:

+421(0)326 526 701

objednavky@insportline.sk

reklamacie@insportline.sk

servis@insportline.sk

Web:

www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: